
## HIGH POWER LED WALL WASHER

MJ-2009A 3W15DRGB



# **User Manual**

----PROFESSIONAL LED LIGHTING -----

Thank you for choosing our LED wall washer light. For the sake of your safety, Please read and follow these instructions carefully and keep this manual in a safe place for future reference

# Catalogue

Chapter	Page
Safety instructions	1
Installation	2
Description	2
DMX-512 control connection	2
DMX-512 connection with DMX terminator	2
Graphic part	3
Display menu	3
Cleaning and maintenance	4
Installation	4
DMX functions and values	5
Technical parameters	5
Warning	6

- ♦ Before open the LED wall washer light and if you want to do the repair work, please make sure the power source is at the separation condition.
- Unceasingly carries on the product improvement about our company the policy, in this instruction booklet carries the data will have the possibility to be able to change in the future, when no longer separate notice change matters concerned. Our company retains when the product improvement changes the related specification the authority. This instruction booklet publisher cannot be responsible regarding this instruction booklet in information accuracy, also cannot the related consequence which causes regarding these information be responsible.

#### **SAFETY INSTRUCTIONS**

This device has left the factory in perfect condition. In order to maintain this condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this user manual.

When unpacking and before disposing of the carton, check there is no transportation damage before using the product. Should there be any damage caused by transportation, consult your dealer and do not use the apparatus.

The device can be use indoors and outdoors, IP65.

The device is not designed or intended to be mounted directly on to inflammable surfaces

The device is only intended for installation, operation and maintenance by professional person.

Do not device the beam onto inflammable surfaces, minimum distance is 5m.

Avoid direct exposure to the light from the lamp. The light is harmful to the eye.

Do not attempt to dismantle or modify the projector in any way.

Electrical connection must only be carried out by qualified personnel.

Before installation, ensure that the voltage and frequency of power supply match the power requirements of the projector.

It is essential that each device is correctly earthed and that electrical installation conforms to all relevant standards.

Do not connect this device to any other types of dimmer apparatus.

Make sure that the power-cord is never crimped or damaged by sharp edges. Never let the power-cord come into contact with other cables. Only handle the power-cord by the plug. Never pull out the plug by tugging the power-cord.

LED lens shall be changed if they have become visibly damaged to such an extent that their effectiveness is impaired, for example by cracks or deep scratches.

Exterior surface temperatures of the luminaire after 5 minutes operation is  $50^{\circ}$  C, when steady state is achieved  $65^{\circ}$  C.

There is no user serviceable parts inside the projector, do not open the housing and never operate the device with the covers removed.

If you have any questions, don't hesitate to consult your dealer or manufacturer.

Always disconnect from the mains, when the device is not in use or before cleaning it or before attempting any maintenance work!



Please do not use the lamp under the water!

Please do not connect the power cable hand by hand over 5 lights per time!

#### DMX FUNCTIONS AND VALUES

7 channel description

Channel	Function	Description	
1CH	Main dimming	Main dimming from dark to bright	
2CH	R dimming	R dimming from dark to bright	
3CH	G dimming	G dimming from dark to bright	
4CH	B dimming	B dimming from dark to bright	
5CH	Main strobe	Main strobe from slow to quick	
6CH	Function speed	Function speed from slow to quick	
7CH	Function Selection	0-50:DMX512, 51-99:jump change;	
		100-150:fade, 151-200:running change;	
		201-250:Pulse, 251-255:sound control	

#### TECHNICAL SPECIFICATIONS

Construction: Aluminum

Power supply: 100V~240V AC,50 Hz /60Hz

LED: 3W\*36LEDs(R:12;G12;B:12)

LED Current: 700mA

Power consumption: max. 150 W

LED Beam Angle: 15°

LED Lifetime: 80,000-100,000 hours

Colour: RGB Mixing colour DMX Channel:3/7CH

Dimming: 0-100% with regulated constant color control

Strobing: 10 Flashes per second (any color)

Operation Modes: DMX512, Internal Program, Sound, Master/slave

Control Panel: Digital 4 Character Alphanumeric Maximum Ambient Temperature:-10 -40° C

Waterproof grade: IP 65 Net weight: 8 KGS Gross weight: 9.2KGS

Packing dimensions: 49x30x19CM

#### INTRODUCTION

Thank you for having chosen our LED lighting Unpack the device ,inside the box you should find:

- 1)LED Wall Washer Light-----1pcs
- 2) Power Cable-----1pcs
- 3) User Manual-----1pcs

Please check carefully that there is no damage caused by transportation. Should there be any ,consult your dealer and don't install this device.

#### DESCRIPTION

#### **Features**

.3/7DMX channels

- .DMX-controlled operation, Sound-controlled operation or stand alone operation with Master/Slave-function
- . Automatic identify Master signal
- . Stepless **RGB** colour changing
- . Equipped with 36 x 3W LEDS:12 x red,12 x blue, 12x green,
- . Switch-mode power supply, 100V-240V
- .Operation very easy, human design, dimming no flicker, jitter phenomena. Can be adapted to video, photography, television and other demanding lighting occasions.

#### **DMX-512 CONTROL CONNECTION**

The product has a DMX 512 input fitted with 3-pin XLR connectors. Screened cables in compliance with EIA RS-485 specifications and the following characteristics must be used for connections:


- 2 conductors plus screen
- 1200hm impedance
- max. transmission rate 250kBaud.

#### DMX-512 CONNECTION WITH DMX TERMINATOR

For installations where the DMX cable has to run a long distance or electrically noisy environment, such as in a discotheque, it is recommended to use a DMX terminator. This helps in preventing

corruption of the digital control signal by electrical noise. The DMX terminator is simply an XLR plug with a 120 OHM resistor connected between pins 2 and 3, which is then plugged into the output XLR socket of the last fixture in the chain.

#### **GRAPHIC PART**



**Operation description:** Press "A" will cycle out seven different functional effect, LED Top row in represent the current function (Reference function table). LED Top row on behalf of the function in the address code, or speed and other parameters. Press  $\bf B$  or  $\bf C$  key can modify the parameter value. Press  $\bf D$  to confirm.

## **DISPLAY MENU** (All the functions are selected, press D to confirm.)

No	Display	Function description
1 A	A001	7 channel address code, (001—512)
	AUUT	B、C button plus or reduce address code value
2 d001	3 channel address code, (001—512)	
	d001	B、C button plus or reduce address code value
3 CC00	Colorful jump, (00—99)	
	CC00	B、C button change jump speed
4	CP00	Colorful pulse variable gradient, (00—99)
		B、C button change speed of pulse and gradient

5 DE00	DEOO	Colorful running, (00—99)
	DE00	B、C button change speed of runnting
6	BEBE	Colorful sound control variable
7 R220	B220	Red dimming, (000—255)
	R220	B、C button change the DMX value of red color
0	0 0000	Green dimming, (000—255)
8 G220	B、C button change the DMX value of red color	
9	B220	Blue dimming, (000—255)
		B、C button change the DMX value of red color

#### Attention: Setting DMX address by button

- 1. press ENTER button when show the **A001/d001** menu, then adjust the DMX address by pressing [UP] or [DOWN] button
- 2. **A001/d001** are master/slave mode

Press [ENTER] to confirm or pressing [ESC] to return to main menu.

#### **CLEANING AND MAINTENANCE**

We recommend a frequent cleaning of the device. Please use a soft lint-free and moistened cloth. Never use alcohol or solvents!

#### **CAUTION!**

Disconnect from mains before starting maintenance operation.

There are no service parts inside the device. Maintenance and service operations are only to be carried out by authorized dealers.

If you need any spare parts, please use genuine parts.

If the power supply cable of this device becomes damaged, it has to be replaced by authorized dealers only in order to avoid hazards.

If you have further questions, please contact your dealer.

#### INSTALLATION

The device must only be installed at a vibration-free, oscilation-free and fire-resistant location.